



ThermaData™ logger Palm™ software

portable temperature logging analysis

- ✓ PalmOS™ PDA/computer compatible
- ✓ manual or auto acquire modes



The ThermaData Palm application has been designed to enable ThermaData logger users to download data without removing the ThermaData logger from its monitoring position. The ThermaData Palm interface plugs into any PalmOS™ hand held PDA/computer's serial connection lead.

There are two methods of download, manual prompts the user for connection of the ThermaData logger and once uploaded the data is shown on screen. Auto acquire mode checks automatically for a connected ThermaData logger. Once the upload is complete a bleep signifies the finish of the process.

Once uploaded from the ThermaData logger the files can be viewed in different formats. The summary gives an overview of the data including start and end dates and times, number of samples taken, alarm settings and number of alarms that have occurred. The graph feature shows the data as a line graph. The zoom feature allows the user to zoom in and view down to 10 samples per screen, then by tapping on a point on the graph the sample number, time, date, temperature value and alarm status of sample are displayed. The data/alarms can be viewed as a list. User notes can be added and attached to the file.

Palm Hotsync transfers the data to a PC where it may be interrogated using the ThermaData logger application. Evaluation and simulation software is available on CD.



examples of how the data can be viewed on a Palm

order code	description	£ each
293-000	Palm interface & software	100.00
<i>the above price is exclusive of Palm computer & cable</i>		

